


Radial (R) Direction

Radial Fluid Flow Into the Wellbore From the Reservoir



Perforated Pipe

R=0

Z=0

Induction Heater [watts]

Axial (Z) Direction

Direction of Fluid Flow

Wellbore

Zone of Induced Heat in the Perforated Pipe [watts]